Guide to reproduce the experiments

This document describes the steps to reproduce the experiments carried out during the investigation.

First, the description of the experiments with the C-Town benchmark and later with the E-Town benchmark are presented.

Experiments for C-Town:

Detection

1. It is necessary to use the BATADAL dataset available at https://www.batadal.net/data.html

Follow Cross_validation script

- 2. In C-town/Main (detection) subdirectory is located the script *Cross_validation.m*. The cross-validation process is carried out to choose the best hyper-parameters for training the Autoencoder. In addition, the AEWMA parameters are adjusted in order to obtain a low rate of false alarms.
 - a) Open *Cross_validation.m* script. Initially, the complete dataset is uploaded, the dataset1 is assigned to vector X and the parameters are established

```
clear
clc
load('batadal.mat')
X = dataset1;
```

b) The function Remove_var_cat receives dataset1 and the outputs are X1 which represents the data from continuous variables and D1 which represents the data from discrete variables. Following, only the vector X1 is used.

c) The outliers of the dataset X1 are eliminated by using the function *Remove_Outliers00*.

```
[X1] = Remove Outliers00(X1); % Remove Outliers of dataset1
```

d) The dataset X1 is normalized with mean value zero (0), and standard deviation one (1).

```
[X1\_,m,sigma] = zscore(X1); % Normalize data with mean value=0 and standard deviation=1
```

For the cross-validation process, it will be necessary to separate the data into several sets. In this case, the proportion 0.2 is selected (prop=0.2 for ktot=5), which means that it is divided into 5 subsets where one of them will be used for validation and the rest for training. The

GetData_CV function receives the normalized data set, the number of subsets, and the ratio. It returns the training and validation subsets (XTrain and XVal respectively).

In the script, the dimension selection of the latent space from 21 to 25 neurons through cross-validation is completed.

The MATLAB function *trainAutoencoder* is used for training. The MATLAB function *predict* is used to obtain the possible output of the Autoencoder. The best hyperparameters are selected.

```
for ii = since:dim
   for j = 1:folds
   X1 = XTrain(:,:,j);
   [samples, var] = size(X1);
   Xtrain = X1';
   Xval = XVal(:,:,j)';
       AE = trainAutoencoder(Xtrain, ii, 'MaxEpochs', 3000,...
           'EncoderTransferFunction','logsig',...
           'DecoderTransferFunction', 'purelin', ...
           'ShowProgressWindow', true, ...
           'L2WeightRegularization', 0.001,...
           'SparsityRegularization',1,...
           'SparsityProportion',0.99);
       % Validation
       Xval = predict(AE, Xval);
       atkAEs det{j,ii} = AE;
       MSE = mse(Xval-Xval);
       MSEs(j,ii) = MSE;
```

```
disp("Dim : "+ii+" Fold : "+j+" MSE: "+MSE+"");
end
end
% Selection of best hyperparameters

mse_average = sum(MSEs);
fold = ones(size(mse_average))*folds;
mse_average = mse_average./fold
```

Follow the Autoencoders_Train script

3. Autoencoder training for cyber-attack detection. The *Autoencoders_Train.m* script located in C-town/Main(detection) subdirectory is used for such purpose. Steps 2a, 2b, and 2c are repeated.

d. Unlike the cross-validation process, the entire training dataset is used here. The Autoencoder is trained with the MATLAB *trainAutoencoder* function.

e. The Xval_variable represents the prediction of the Autoencoder when ingesting the data after being trained.

f. The SPE is calculated with the original data and the prediction. This gives information about the error obtained when data from normal system operation is analyzed.

```
SPE = diag(sqrt((Xval - Xval_)' * (Xval - Xval_))); % Prediction
error (SPE)
    MSE = mse(Xval - Xval )
```

g. Save in the *atksAEs_det.mat* variable the trained Autoencoder and the SPE for normal system operation.

```
%% Save
save atkAEs det.mat AE det SPE
```

Follow Autoencoders_Test script

- 4. To check the effectiveness of the above process, the *Autoencoders_Test.m* script located in in C-town/Main(detection) subdirectory is used.
 - a. The three data sets are loaded, and steps 2.a, 2.b and 2.c are repeated in each of the sets, obtaining X1, X2, and X3 from dataset1, dataset2 and dataset3, respectively.
 - The test data set is manually normalized by using the mean and standard deviation of the training data set.

```
clear
clc
load('batadal.mat')
load('atkAEs det.mat')
load('Batadal result.mat')
% Xn: continuous variables of datasetn
% Dn: discrete variables of datasetn
[X1, D1] = Remove var cat(dataset1);
[X2, D2] = Remove_var_cat(dataset2);
[X3, D3] = Remove var cat(dataset3);
[X1] = Remove Outliers00(X1);
                                % Remove Outliers of dataset1
[samples, \sim] = size(X3);
[X1, m, sigma] = zscore(X1);
                                           % Normalice normal data
[\sim, var] = size(X3);
for i = 1:samples
                                           % Normalice attack data
   aux = X3(i,:) - m;
    for j = 1:var
       Xtest(i,j) = aux(j)/sigma(j);
    end
```

b. In *Xtest* is stored the data from dataset3. In *Ytest* is stored the actual outputs that identify as "1" an attack and "0" a non-attack (this is used for testing). P_SPE represents the new SPE obtained by comparing the original data (*Xtest*) with the prediction given by the Autoencoder (*P Xtest*).

```
%% TEST
```

```
P_Xtest = predict(AE_det, Xtest);
Output prediction
P_SPE = diag(sqrt((Xtest - P_Xtest)' * (Xtest - P_Xtest)));
Prediction error (SPE)
```

c. The AEWMA function located in C-town/Main(detection) subdirectory is used to classify observations into attacks or non-attacks. AEWMA receives as parameters *P_SPE, SPE, minimum delta, maximum delta,* and *arl*. The function returns the *atks det* array with the classification of each of the samples.

d. The indices TPR, TNR, Sclf, FAR, FDR and precision are calculated.

```
%% Classification check
Result = zeros(7,1);
    tot A = 0;
   tot_NA = 0;
   TP = 0;
                                % System under attack and attack detected
   TN = 0;
                                % System without attack and without attack
detection
   FP = 0;
                                % System under attack and without attack
detection
   FN = 0;
                                % System without attack and attack
detected
    for ii = 1:samples
            if((Ytest(ii,1) == 1) && (atks det(ii,1) == 1))
                TP = TP + 1;
            elseif ((Ytest(ii,1) == 0) && (atks det(ii,1) == 0))
                TN = TN + 1;
            elseif ((Ytest(ii,1) == 0) && (atks det(ii,1) == 1))
                FP = FP + 1;
            elseif ((Ytest(ii,1) == 1) && (atks det(ii,1) == 0))
                FN = FN + 1;
```

```
end
    end
    TPR = TP/(TP + FN);
                                                           %TPR = TP/(TP +
FN) True Positive Rate
    TNR = TN/(FP + TN);
                                                           %TNR = TN/(FP +
TN) True Negative Rate
    Sclf = (TPR + TNR)/2;
    FAR = (FP/(FP+TN))*100;
    FDR = TPR*100;
    TP;
    FN;
    recall = TP/(TP+FN)
    precision = TP/(TP+FP)
    F1 = 2*(recall*precision)/(recall+precision)
ms(1,1) = FDR;
ms(1,2) = FAR;
ms(1,3) = arl;
ms(1,4) = d;
ms(1,5) = d2;
X = ['ARL :', num2str(arl)];
disp(X)
disp('')
        e. To check the rapid detection, the STTD index is found
%% Checking fast detection
```

gamma = 0.5;na = 0;td = 0;t0 = 0;TTD = zeros(1,1);flag = 0;delta t = zeros(1,1);for ii = 1:samples if(ii == 1) if(Ytest(ii,1) == 1) t0 = ii;na = na + 1; $if(atks_det(ii,1) == 1)$ td = ii;flag = 1;end elseif(Ytest(ii,1) == 1 && Ytest(ii-1,1) == 0)

```
t0 = ii;
        na = na + 1;
        if(atks_det(ii, 1) == 1)
            td = ii;
            flag = 1;
    elseif(Ytest(ii,1)==1 && Ytest(ii-1,1)==1)
        if(atks det(ii,1)==1 && flag == 0)
            td = ii;
            flag = 1;
        end
    elseif(Ytest(ii,1) == 0 && Ytest(ii-1,1) == 1)
        flag = 0;
        TTD(na,1) = td - t0;
        delta t(na,1) = ii - t0;
    end
end
sum aux = 0;
for ii = 1:na
    aux = TTD(ii, 1)/delta t(ii, 1);
    sum aux = sum aux + aux;
end
```

f. With both indicators, a global indicator S is formulated.

```
STTD = 1 - ( (1/na)*sum_aux )
Sclf
S = gamma * STTD + (1-gamma)*Sclf
```

g. The results are shown.

```
%% To point out the False alarms in the figures
[atks_det1,signal_e] = AEWMA(P_SPE,SPE,d,d2,arl);

value_fa = 0;
times_fa = 0;
cont = 1;
for ii = 1:samples
    if(atks_det(ii,1)>Ytest(ii,1))
        times_fa(cont) = ii;
        value_fa(cont) = signal_e(1,ii);
        cont = cont +1;
    end

end
```

figure

```
plot(P SPE);grid on; hold on; plot(Ytest*3);
legend('SPE de Xtest', 'Attacks');
figure
plot(atks det1,'linewidth',1.5);grid on; hold on; plot(Ytest);
legend('SPE', 'Attack interval');
title('Detection')
P SPE1 = P SPE;
figure
a = area(atks det1);
a.FaceColor = 'black';
a.FaceAlpha = 0.2;
a.LineStyle = 'none';
e = {'no-attack', 'attack'};
set(gca, 'YTick', 0:1:length(e)+1);
set(gca, 'YTickLabel', e);
set(gca,'XTick',0:100:samples+1);
hold on;
plot(Ytest, 'Color', 'black');
legend('detected attacks', 'real attacks')
figure
umbral = ones(samples, 1) *1.0385;
falsa alarma = atks det1' - Ytest;
p = plot(signal e);
p.Color = [0 \ 0.4470 \ 0.7410];
p.LineWidth = 1.5;
hold on;
plot(Ytest*10, 'Color', 'black');
hold on;
p = plot(umbral, 'Color', 'red');
p.LineWidth = 1.5;
hold on;
p = plot(times fa, value fa, 'o');
p.Color = [0.4\overline{6}60 \ 0.674\overline{0} \ 0.1880];
ylabel('Attack Indicator');
xlabel('Observations');
legend('z(t)','time interval of attack','limit of control chart','false
alarm')
%% Save
save atks det1.mat atks det1
save P SPE1.mat P SPE1
```

Location

5. The localization experiment consists of training an Autoencoder for each ARRs. In this case, the first step is to find the variables to consider in each ARR using Structural Analysis.

- a. In the C-town\Structural Analysis\src subdirectory is located the ctown.m script. In it are declared the model variables and the possible types of attacks. (model.x, model.z and model.f). (Please, read the Structural Analysis software User Manual)
- b. Declare the equations that relate the variables and attacks in model.rels (Please, see the Structural Analysis Software User Manual).
- c. Check the figures obtained. Obtain the ARRs.
- 6. In C-town\Main (localization) subdirectory is located the information related to each ARR. In each subdirectory, the reader will find all scripts and functions used for that ARR. For each ARR, it is necessary to develop steps 2 and 3 explained in detection.
- 7. To verify the location results the *main.m script* located in Ctown/Mail(localization) subdirectory is used.

Follow main.m script

a. Upload information correspondig to each ARR.

```
% MAIN Localization AE
   clear
   clc
   load('batadal.mat')
   addpath('Group 1 (data normal)')
   addpath('Group 2 (data normal)')
   addpath('Group 3 (data normal)')
   addpath('Group 4 (data normal)')
   addpath('Group 5 (data normal)')
   addpath('Group 6 (data normal)')
   addpath('Group 7 (data normal)')
   % addpath('auxiliar')
   load('atks det1.mat')
   load('atks det2.mat')
   load('atks det3.mat')
   load('atks det4.mat')
   load('atks det5.mat')
   load('atks det6.mat')
   load('atks det7.mat')
%Initialization the variables samples, groups, atks and Y test
[samples,~] = size(atks det1);
groups = 7;
atks = 6;
Ytest = labels3;
```

b. The *alabels* array represents the actual classification for each attack. To obtain it, the *Atk_selection* function is used. The objective is to create a labeled output (Ytest) for each DMA.

c. The *adiagnostic* array represents the classification obtained by using the methodology proposed in the paper. It is obtained from structural analysis.

d. Verify if the attack is detected in the correct DMA. For this, the *inZone* variable is used.

e. Find attack location performance metrics.

```
%% Statistics of each attack
num_atk = 0;
num_atks = zeros(samples,1);
```

```
times = zeros(atks,2);
t = 1;
c_atks = 0;
                    % Times counter under attack
                   % Times counter under attack that are located in the
c correct = 0;
correct zone
c moreOne = 0;
                   % Times counter under attack that are located in more
one zone
c ok = 0;
                    % Times counter under attack that are located only in
the correct zone
c atkDet = 0;
                    % Times counter under attack detected
for ii = 1:samples
    if(ii == 1)
        if(Ytest(ii) == 1)
            num atk = num atk + 1;
            num atks(ii) = num atk;
        end
    end
    if (ii~=1)
        if (Ytest(ii) == 1 && Ytest(ii-1) == 0)
            num atk = num atk + 1;
            num atks(ii,1) = num atk;
            times(t,1) = ii;
            % Attack start
            c atks = c atks + 1;
            if(inZone(ii) == 1)
                c correct = c correct + 1;
            end
            if (magDiag(ii)>1)
                c moreOne = c moreOne + 1;
            if(inZone(ii) == 1 && magDiag(ii) == 1)
                c ok = c ok + 1;
            if (magDiag(ii)>0)
                c atkDet = c atkDet + 1;
        elseif(Ytest(ii,1)==1 && Ytest(ii-1)==1)
            num_atks(ii,1) = num_atk;
            % During an attack
            c atks = c atks + 1;
            if(inZone(ii) == 1)
                c correct = c correct + 1;
            if (magDiag(ii)>1)
                c_moreOne = c moreOne + 1;
            if(inZone(ii) == 1 && magDiag(ii) ==1)
                c ok = c ok + 1;
            end
            if (magDiag(ii) > 0)
                c atkDet = c atkDet + 1;
```

```
elseif(Ytest(ii) == 0 && Ytest(ii-1) ==1)
            times(t,2) = ii;
            % Attack end
            disp(" ");
            disp("ATTACK #: "+t+"");
            aux = c atkDet*100/c atks;
            disp(" Localized attacks: "+aux+"% ("+c atkDet+")");
            aux = c_correct*100/c_atkDet;
            disp("
                       Attacks located in the correct area: "+aux+"%
("+c correct+")");
            aux = c_moreOne*100/c_atkDet;
            disp("
                       Attacks located in more than one area: "+aux+"%
("+c moreOne+")");
            aux = c ok*100/c atkDet;
            disp("Attacks located only in the correct area: "+aux+"%
("+c ok+")");
            c atks = 0;
            c correct = 0;
            c moreOne = 0;
            c ok = 0;
            c atkDet = 0;
            t = t + 1;
        end
    end
end
clear num atk t
       f. The results are shown.
%% Show results
figure
plot(magDiag); grid on; hold on;
xlabel('Time')
ylabel ('Number of areas where an attack was detected')
figure
plot(adiagnostic(298:367,1),'o'); grid on; hold on;
plot(adiagnostic(298:367,2)*2,'o'); grid on; hold on;
plot(adiagnostic(298:367,3)*3,'o'); grid on; hold on;
plot(adiagnostic(298:367,4)*4,'o'); grid on; hold on;
plot(adiagnostic(298:367,5)*5,'o'); grid on; hold on;
plot(adiagnostic(298:367,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk1');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca,'YTick',0:1:length(e)+1);
set(gca,'YTickLabel',e);
```

```
figure
plot(adiagnostic(633:697,1),'o'); grid on; hold on;
plot(adiagnostic(633:697,2)*2,'o'); grid on; hold on;
plot(adiagnostic(633:697,3)*3,'o'); grid on; hold on;
plot(adiagnostic(633:697,4)*4,'o'); grid on; hold on;
plot(adiagnostic(633:697,5)*5,'o'); grid on; hold on;
plot(adiagnostic(633:697,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk2');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca,'YTick',0:1:length(e)+1);
set(gca, 'YTickLabel', e);
figure
plot(adiagnostic(868:898,1),'o'); grid on; hold on;
plot(adiagnostic(868:898,2)*2,'o'); grid on; hold on;
plot(adiagnostic(868:898,3)*3,'o'); grid on; hold on;
plot(adiagnostic(868:898,4)*4,'o'); grid on; hold on;
plot(adiagnostic(868:898,5)*5,'o'); grid on; hold on;
plot(adiagnostic(868:898,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk3');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca,'YTick',0:1:length(e)+1);
set(gca,'YTickLabel',e);
figure
plot(adiagnostic(938:968,1),'o'); grid on; hold on;
plot(adiagnostic(938:968,2)*2,'o'); grid on; hold on;
plot(adiagnostic(938:968,3)*3,'o'); grid on; hold on;
plot(adiagnostic(938:968,4)*4,'o'); grid on; hold on;
plot(adiagnostic(938:968,5)*5,'o'); grid on; hold on;
plot(adiagnostic(938:968,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk4');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca, 'YTick', 0:1:length(e)+1);
set(gca, 'YTickLabel', e);
figure
plot(adiagnostic(1230:1329,1),'o'); grid on; hold on;
plot(adiagnostic(1230:1329,2)*2,'o'); grid on; hold on;
plot(adiagnostic(1230:1329,3)*3,'o'); grid on; hold on;
plot(adiagnostic(1230:1329,4)*4,'o'); grid on; hold on;
plot(adiagnostic(1230:1329,5)*5,'o'); grid on; hold on;
plot(adiagnostic(1230:1329,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk5');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca, 'YTick', 0:1:length(e)+1);
set(gca, 'YTickLabel', e);
plot(adiagnostic(1575:1654,1),'o'); grid on; hold on;
plot(adiagnostic(1575:1654,2)*2,'o'); grid on; hold on;
plot(adiagnostic(1575:1654,3)*3,'o'); grid on; hold on;
plot(adiagnostic(1575:1654,4)*4,'o'); grid on; hold on;
plot(adiagnostic(1575:1654,5)*5,'o'); grid on; hold on;
plot(adiagnostic(1575:1654,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk6');
```

```
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca,'YTick',0:1:length(e)+1);
set(gca,'YTickLabel',e);

figure
plot(adiagnostic(1941:1970,1),'o'); grid on; hold on;
plot(adiagnostic(1941:1970,2)*2,'o'); grid on; hold on;
plot(adiagnostic(1941:1970,3)*3,'o'); grid on; hold on;
plot(adiagnostic(1941:1970,4)*4,'o'); grid on; hold on;
plot(adiagnostic(1941:1970,5)*5,'o'); grid on; hold on;
plot(adiagnostic(1941:1970,6)*6,'o'); grid on; hold on;
title('Diagnosis during Atk7');
e = {' ','dma1','dma6','dma2','dma3','dma4','dma5'};
set(gca,'YTick',0:1:length(e)+1);
set(gca,'YTickLabel',e);
```

Experiments for E-Town:

Generate data sets

- 1. It is necessary to install Epanet2 software package. Open ETown_wPLCs.inp to perform expert analysis. The aim is to divide the network to apply the methodology. Resulting in the division of the network into three zones.
- 2. The datasets used for this experiment were generated with the epanetCPA-master tool downloaded from https://github.com/rtaormina/epanetCPA with the etown scenario by using the main.m script.

Structural Analysis

- 3. It is necessary to develop a structural analysis for each zone. The procedure is similar to C-Town localization experiment. An Autoencoder must be trained for each ARR. The first step is to find the variables to consider in each ARR. Develop the procedure explained in step 5 of c-town experiments.
 - a. In the E-town/Structural Analysis/src folder use the *etown2_1.m*, *etown2_2.m*, *and etown2_3.m* scripts to obtain the variables of the ARRs groups for zone 1, zone 2, and zone 3 respectively.
- 4. In E-town/Main subdirectory are located the *Zone 1.m, Zone2.m, and Zone3.m* scripts, used for training the Autoencoders of the ARRs in the three zones.

Follow Zone1.m script

a. Load the data SCADA_readings.mat which contains the training and test data.

```
load('SCADA readings.mat'); % load raw datasets
```

b. Create the labeled outputs to check the results that are obtained.

```
% labels for the dataset with the first 10 attacks
evtr{1} = (600:630);
evtr{2} = (1000:1040);
evtr{3} = (1400:1500);
evtr{4} = (2000:2100);
evtr{5} = (2600:2700);
evtr{6} = (2600:2700);
evtr{7} = (3300:3400);
evtr{8} = (3350:3450);
evtr{9} = (3400:3500);
evtr{10} = (4000:4050);
Y val = zeros(height(SCADA val),1);
Y val([\text{evtr}{1}] evtr{2} evtr{3} evtr{4} evtr{5} evtr{6} evtr{7} evtr{8}
evtr{9} evtr{10}]) = 1; %events flags for train
Y val=Y val(1:end); %to have full days in the dataset
% labels for each DMA
Y vl = zeros(height(SCADA val),24);
Y vl([evtr\{3\} evtr\{10\}],6) = 1; %atk 6
Y vl([evtr{2}],11) = 1; %atk 11
Y_vl([evtr{8}],16) = 1; %atk 16
Y vl([evtr{9}],17) = 1; %atk 17
Y = V([evtr{7}], 18) = 1; %atk 18
Y vl([evtr{6}],20) = 1; %atk 20
Y vl([evtr{5}],21) = 1; %atk 21
Y vl([evtr{4}],22) = 1; %atk 22
Y vl([evtr{1}],24) = 1; %atk 23cd
% labels for dataset with the other 10 attacks
evts{1} = (387:487);
evts{2} = (937:987);
evts{3} = (1387:1407);
evts{4} = (1887:2037);
evts{5} = (2687:2737);
evts{6} = (2712:2762);
evts{7} = (2907:3057);
evts{8} = (3187:3257);
evts{9} = (3887:3967);
evts{10}=(3887:3977);
Y test=zeros(height(SCADA test),1);
Y test([\text{evts}\{1] \text{ evts}\{2] \text{ evts}\{3\} \text{ evts}\{4\} \text{ evts}\{5\} \text{ evts}\{6\} \text{ evts}\{7\} \text{ evts}\{8\}
evts{9} evts{10}])=1; %events flags for test
Y test=Y test(1:end); %to have full days in the dataset
% labeld for each DMA
Y ts = zeros(height(SCADA test), 24);
Y ts([evts{8}],1) = 1; %atk 1
Y ts([evts{2}],2) = 1; %atk 2
Y ts([evts{3}],3) = 1; %atk 3
Y ts([evts{4}],6) = 1; %atk 6
Y ts([evts{5}] evts[6]],13) = 1; %atk 13
Y ts([evts{1}] evts{7}],22) = 1; %atk 22
Y ts([evts{9} evts{10}],24) = 1; %atk 23cd
```

- The variable evtr represents the time intervals in which the first 10 attacks occur.
- The variable evts represents the time intervals in which the last 10 attacks occur.
- The variable *Y_val* contains the labeled output of the first 10 attacks.
- The variable Y_test contains the labeled output of the last 10 attacks.
- The variable *Y_vI* and the variable *Y_ts* contain the labeled outputs corresponding to each DMA.
 - c. Structural analysis indicates that Zone 1 should have six ARRs. The next step is to train an Autoencoder for each one of them.
 - AdmasN variable: presents the groups of ARRs in which an attack must be detected at the same time, in order to locate it in that DMA. N is the zone number: N= 1,2,3.
 - ARRsN array: presents the variables present in each ARR in the different zones.

```
load('ARRs1.mat')
```

Save in Xtrain the training data corresponding to the analyzed ARR, in X_val and X_test the test data, the first 10 attacks, and the next 10 attacks respectively.

```
%% This steps should be repeated for each ARR in the analyzed zone
a = 1;

X_train = SCADA_train(:,ARRs1{a,1});
X_test = SCADA_test(:,ARRs1{a,1});
X val = SCADA val(:,ARRs1{a,1});
```

 Remove constant variables with the RemoveConstant function which receives the training data and the test data and returns those arrays with the constants removed.

```
[Xtn,Xts] = RemoveConstant(X_train,X_test); % Remove constant variables
and time variable
[~,Xvl] = RemoveConstant(X_train,X_val); % Remove constant variables and
time variable
```

Normalize training data with the Matlab zscore command.

```
[X1 ,m,sigma] = zscore(Xtn); % Normalize data normal
```

• Normalize test data with the *normaldata* function which receives the mean and standard deviation of the training data, and the data to be normalized.

Finally, train the Autoencoder with the AEtrain function, which receives the training data, the dimension of the latent space and the hyper-parameters L2, SR, and SP. The function returns the trained Autoencoder, the SPE, and the MSE.

```
[AEs\{a,1\}, SPEs\{a,1\}, MSEs\{a,1\}]=AEtrain(X1,5,0.001,1,0.99);
```

 To test the data, the AEtest function is used, which receives the information about the corresponding Autoencoder and the test data and returns the P SPE.

```
[P_SPE{a,2}] = AEtest(AEs{a,1},X3_);
[P_SPE{a,1}] = AEtest(AEs{a,1},X2_);
```

5. Repeat step 4 for each Zone.

Follow MAIN.m script

- 6. The verification of the obtained results is implemented in MAIN.m.
 - a. Load data.

```
load('SCADA readings.mat'); % load raw datasets
```

b. *PepareData* function is used to obtain the labeled outputs in the same form as step 4.b from E-Town

```
[evtr,evts,evtss,Y val,Y vl,Y test,Y ts]=PepareData(SCADA val,SCADA test);
```

- c. Analyze the detection and location in each zone (j = zone number).
- d. Apply AEWMA similar to step 4.d in the C town experiments.
- e. Show the 24 DMA answer individually.

```
%% Step 2: AEWMA for each ARR
for j = 1:3
    %% Zone 1
    if(j==1)
        load('Response1.mat')
        load('ARRs1.mat')
        [count RR,~] = size(P SPE);
        d_{-} = 0.9;
d_{-} = 5;
arl_{-} = 900;
         for i = 1:count RR
             [atks det{i,1},\sim] = AEWMA(P SPE{i,1},SPEs{i,1},d ,d2 ,arl );
             [atks_det{i,2},\sim] = AEWMA(P_SPE{i,2},SPEs{i,1},d_,d2_,arl_);
        end
         [count,~] = size(admas1);
         for i = 1:count
             b val\{i,1\} = atks det(admas1\{i,1\},1);
             b test{i,1} = atks det(admas1{i,1},2);
```

```
[cc, \sim] = size(b test{i,1});
            aux = ones(size(Y test'));
            aux2 = ones(size(Y val'));
            for ii = 1:cc
                 aux = aux .* b test{i,1}{ii,1};
                 aux2 = aux2 .* b val{i,1}{ii,1};
            det dma\{i,1\}= aux2;
            det dma\{i,2\} = aux;
            figure
subplot(2,1,1);area(det dma{i,1},'FaceColor','blue','LineStyle','none','Fa
ceAlpha', 0.4); hold on; plot(Y val, 'Color', 'k');
            title(['Response of attack to DMA', num2str(i)])
            xlabel('First 10 attacks')
            e = {'Normal','Under Attack'};
            set(gca,'YTick',0:1:length(e)+1);
            set(gca, 'YTickLabel', e);
            legend({'Detected attacks','Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
subplot(2,1,2);area(det dma{i,2},'FaceColor','blue','LineStyle','none','Fa
ceAlpha', 0.4); hold on; plot(Y_test, 'Color', 'k');
            xlabel('Another 10 attacks')
            e = {'Normal', 'Under Attack'};
            set(gca, 'YTick', 0:1:length(e)+1);
            set(gca, 'YTickLabel', e);
            legend({'Detected attacks','Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
            filename = ['Response of attack to DMA', num2str(i), '.fig'];
            saveas(gcf, filename);
        end
    end
    clear atks det
%% Zone 2
    if(j==2)
        load('Response2.mat')
        load('ARRs2.mat')
        [count RR,~] = size(P SPE);
        arl = 100;
        d2_{-} = 5;
        d = 1.5;
        for i = 1:count RR
            [atks det{i,1},\sim] = AEWMA(P SPE{i,1},SPEs{i,1},d ,d2 ,arl );
            [atks det\{i,2\},\sim] = AEWMA(P SPE\{i,2\}, SPEs\{i,1\}, d , d2 , arl );
        end
        [count, \sim] = size(admas2);
        for i = 1:count
            b val{7+i,1} = atks_det(admas2{i,1},1);
            b test\{7+i,1\} = atks det(admas2\{i,1\},2);
            [cc, \sim] = size(b test{7+i,1});
            aux = ones(size(Y test'));
            aux2 = ones(size(Y val'));
            for ii = 1:cc
                 aux = aux .* b test{7+i,1}{ii,1};
                 aux2 = aux2 .* b_val{7+i,1}{ii,1};
            end
```

```
det dma{7+i,1}=aux2;
            det dma\{7+i,2\}=aux;
            figure
subplot(2,1,1); area(det dma{7+i,1}, 'FaceColor', 'blue', 'LineStyle', 'none', '
FaceAlpha', 0.4); hold on; plot(Y val, 'Color', 'k');
            title(['Response of attack to DMA', num2str(7+i)])
            xlabel('First 10 attacks')
            e = {'Normal','Under Attack'};
            set(gca,'YTick',0:1:length(e)+1);
            set(gca, 'YTickLabel', e);
            legend({'Detected attacks','Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
subplot(2,1,2);area(det dma{7+i,2},'FaceColor','blue','LineStyle','none','
FaceAlpha',0.4);hold on;plot(Y_test,'Color','k');
            xlabel('Another 10 attacks')
            e = {'Normal', 'Under Attack'};
            set(gca, 'YTick', 0:1:length(e)+1);
            set(gca, 'YTickLabel', e);
            legend({'Detected attacks', 'Real
attacks'},'Location','bestoutside','NumColumns',1)
            filename = ['Response of attack to DMA', num2str(7+i),'.fig'];
            saveas(gcf, filename);
        end
    end
    clear atks det
    %% Zone 3
    if(j==3)
        load('Response3.mat')
        load('ARRs3.mat')
        [count RR,~] = size(P SPE);
        d = 0.5;
        d2 = 6;
        arl = 700;
        for i = 1:count RR
             [atks det{i,1},\sim] = AEWMA(P SPE{i,1},SPEs{i,1},d,d2,arl);
             [atks det\{i,2\},~] = AEWMA(P SPE\{i,2\},SPEs\{i,1\},d,d2,arl);
        end
        [count, \sim] = size(admas3);
        for i = 1:count
            if (i==1)
                 b val\{7,1\} = atks det(admas3\{i,1\},1);
                 b test\{7,1\} = atks det(admas3\{i,1\},2);
                [cc, \sim] = size(b test{7,1});
                 aux = ones(size(Y test'));
                 aux2 = ones(size(Y val'));
                 for ii = 1:cc
                     aux = aux .* b test{7,1}{ii,1};
                     aux2 = aux2 .* b val{7,1}{ii,1};
                 end
                 det dma\{7,1\}= aux2;
                 det dma{7,2} = aux;
                 figure
```

```
subplot(2,1,1);area(det dma{7,1},'FaceColor','blue','LineStyle','none','Fa
ceAlpha', 0.4); hold on; plot(Y val, 'Color', 'k');
                title(['Response of attack to DMA', num2str(7)])
                xlabel('First 10 attacks')
                e = {'Normal','Under Attack'};
                set(gca, 'YTick', 0:1:length(e)+1);
                set(gca, 'YTickLabel', e);
                legend({'Detected attacks','Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
subplot(2,1,2);area(det_dma{7,2},'FaceColor','blue','LineStyle','none','Fa
ceAlpha', 0.4); hold on; plot(Y test, 'Color', 'k');
                xlabel('Another 10 attacks')
                e = {'Normal','Under Attack'};
                set(gca,'YTick',0:1:length(e)+1);
                set(gca,'YTickLabel',e);
                legend({'Detected attacks','Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
                filename = ['Response of attack to
DMA', num2str(7), '.fig'];
                saveas(gcf, filename);
            else
                b val\{10+i,1\} = atks det(admas3\{i,1\},1);
                b test\{10+i,1\} = atks det(admas3\{i,1\},2);
                [cc, \sim] = size(b test{10+i,1});
                aux = ones(size(Y test'));
                aux2 = ones(size(Y_val'));
                for ii = 1:cc
                     aux = aux .* b test{10+i,1}{ii,1};
                     aux2 = aux2 .* b val{10+i,1}{ii,1};
                end
                det dma{10+i,1} = aux2;
                det dma{10+i,2} = aux;
                figure
subplot(2,1,1);area(det_dma{10+i,1},'FaceColor','blue','LineStyle','none',
'FaceAlpha', 0.4); hold on; plot(Y val, 'Color', 'k');
                title(['Response of attack to DMA', num2str(10+i)])
                xlabel('First 10 attacks')
                e = {'Normal','Under Attack'};
                set(gca,'YTick',0:1:length(e)+1);
                set(gca, 'YTickLabel', e);
                legend({'Detected attacks','Real
attacks'},'Location','bestoutside','NumColumns',1)
subplot(2,1,2);area(det dma{10+i,2},'FaceColor','blue','LineStyle','none',
'FaceAlpha', 0.4); hold on; plot(Y test, 'Color', 'k');
                xlabel('Another 10 attacks')
                e = {'Normal','Under Attack'};
                set(gca, 'YTick', 0:1:length(e) +1);
                set(gca,'YTickLabel',e);
                legend({'Detected attacks','Real
attacks'},'Location','bestoutside','NumColumns',1)
                filename = ['Response of attack to
DMA', num2str(10+i), '.fig'];
```

```
saveas(gcf, filename);
end
end
end
end
```

f. Show and analyze the other results. In this case, it is necessary to concatenate the 20 attacks, storing them in the *accum* variable.

```
%% Step 3: Show results of detection
% Label for general detection
[samples ts, var] = size(Y ts);
[samples vl,~] = size(Y vl);
Y = zeros(samples_ts+samples_v1,1);
Y(1:samples vl,1) = Y val;
Y(samples vl+1:end,1) = Y test;
labels = zeros(samples_ts+samples_vl,var);
labels(1:samples vl,:) = Y vl;
labels(samples vl+1:end,:) = Y ts;
% Data for general detection
[atks,~] = size(det dma);
accum = zeros(1, samples ts+samples v1);
for i = 1:atks
    aux = zeros(1, samples ts+samples vl);
    aux(1,1:samples vl) = det dma{i,1};
    aux(1, samples vl+1:end) = det dma{i,2};
    det dma{i,3} = aux;
    accum = accum+aux;
end
```

g. Using the *CheckDetection* function, the TPR, TNR, Sclf, FAR, FDR, STTD, and S indices are obtained. The function receives the variable with the attack detection (*accum*) and the actual labeled output of the system (Y), and returns the indices.

```
[TPR, TNR, Sclf, FAR, FDR, STTD, S] = CheckDetection(accum, Y)
r = find(accum>1);
accum(r)=1;
```

h. Obtain the incidence matrix with the *IncMatrix* function. It receives the *labels* variable that represents the real labeled output of each DMA separately. The *det_dma* variable represents the labeled output obtained from each DMA separately and the *Y* variable represents the actual outputs

```
[matrix,porcentual_matrix] = IncMatrix(labels,det_dma,Y);
```

i. plotAtks function allows to view the detection of each attack individually.

```
figure
area(accum, 'FaceColor', 'blue', 'LineStyle', 'none', 'FaceAlpha', 0.4); hold
on; plot(Y, 'Color', 'k');
e = {'Normal', 'Under Attack'};
set(gca, 'YTick', 0:1:length(e)+1);
set(gca, 'YTickLabel', e);
xlabel('Time')
title('Detection of attacks')
legend({'Detected attacks', 'Real
attacks'}, 'Location', 'bestoutside', 'NumColumns', 1)
filename = ['Detection of attacks.fig'];
saveas(gcf, filename);

[Results] = plotAtks(det_dma, evtr, evtss, labels);
```